

2 Industrial Park Road Carmichaels PA 15320 800-928-9995 customers@ubelting.com www.universalbelting.com This sheet is a guideline only. Every press is a little different. We recommend that you do a test splice with your press before attempting the actual belt splice.

140200

0/2EC-0 Pet/Cotton Bare White

Splice (options)	Pressure (psi)	Temperature		Press	Foil	Foil	Skive Length
		TOP	BOTTOM	Time	(position)	(type)	(inch)
Finger Splice - Water Cooled	20	170° C 338° F	170° C 338° F	1 minute	1 Piece Bottom	PU	N/A
Finger over Finger - Water Cooled	20	170° C 338° F	170° C 338° F	1 minute	1 Piece Middle	PVC	N/A
Finger Splice - High Speed	20	170° C 338° F	170° C 338° F	2 minutes	1 Piece Bottom	PU	N/A
Mechanical Lace		# 36 Series (Clipper)					
		#7 (Alligator)					
Notes: Rough Teflon Top and Bottom							
Recommended Joining Procedures: Finger Splice							

