

2 Paisley Park Carmichaels PA 15320 800-928-9995 customers@ubelting.com www.universalbelting.com This sheet is a guideline only. Every press is a little different. We recommend that you do a test splice with your press before attempting the actual belt splice.

100605

U0/1E GREEN

Splice (options)	Pressure (psi)	Temperature		Press	Foil	Foil	Skive
		TOP	воттом	Time	(position)	(type)	Length (inch)
Finger Splice - Water Cooled	20	160° C 320° F	160° C 320° F	30 seconds	Bottom	PU Foil	N/A
Lap Splice - Water Cooled	25	160° C 320° F	160° C 320° F	30 seconds	Middle	PU Foil	.25"

Note: For lap splice - lightly buff .25" area before applying foil

Recommended Joining Procedure: Finger Splice

