

Recommended Joining Procedure: Finger Splice

2 Paisley Park Carmichaels PA 15320 800-928-9995 customers@ubelting.com www.universalbelting.com This sheet is a guideline only. Every press is a little different. We recommend that you do a test splice with your press before attempting the actual belt splice.

130401

AM-U92/2ENF-AS M BLUE

Splice (options)	Pressure (psi)	Temperature		Press	Foil	Foil	Skive
		TOP	воттом	Time	(position)	(type)	Length (inch)
Finger Splice - Water Cooled	20	155° C 311° F	150° C 302° F	30 seconds	Тор	PU Foil	N/A
Finger Splice - Carbon Fiber High Speed	15	160° C 320° F	150° C 302° F	30 seconds	Тор	PU Foil	N/A
Mechanical Lacing		UCM 36 X SP (Clipper)					
		# 00 (Alligator)					
Notes: Use matt release paper on top and Silicone or PTFE on bottom.							

