

Recommended Joining Procedure: Finger Splice

2 Paisley Park Carmichaels PA 15320 800-928-9995 customers@ubelting.com www.universalbelting.com This sheet is a guideline only. Every press is a little different. We recommend that you do a test splice with your press before attempting the actual belt splice.

110100

U85/1 ES M WHITE

Splice (options)	Pressure (psi)	Temperature		Press	Foil	Foil	Skive
		ТОР	воттом	Time	(position)	(type)	Length (inch)
Finger Splice - Water Cooled	20	160° C 320° F	160° C 320° F	30 seconds	Тор	PU Foil	N/A
Finger Splice - Carbon Fiber High Speed Press	20	160° C 320° F	160° C 320° F	30 seconds	Тор	PU Foil	N/A
Mechanical Lace		Not recommended					
		Not recommended					
Note: Matt Release on top							

