

Recommended Joining Procedure: Finger Splice

2 Paisley Park Carmichaels PA 15320 800-928-9995 customers@ubelting.com www.universalbelting.com This sheet is a guideline only. Every press is a little different. We recommend that you do a test splice with your press before attempting the actual belt splice.

110700

UU92/2ES NPY GLOSS LT BLUE

Splice (options)	Pressure (psi)	Temperature		Press	Foil	Foil	Skive
		ТОР	воттом	Time	(position)	(type)	Length (inch)
Water Cooled	25	165° C 329° F	165° C 329° F	60 Seconds	1-Top 1-Bottom	PU Foil	N/A
High Speed	25	165° C 329° F	165° C 329° F	120 Seconds	1-Top 1-Bottom	PU Foil	N/A
Mechanical Lacing Note: Gloss Release Paper on Top / Impression Pad on Bott		#36 Series (Clipper)					
		# 1 (Alligator)					

Single Finger
-Prepared or Finished